



## Installation instructions for the Leica M10

### Firmware 1.10.4.0

Dear Customers,

Installing the firmware 1.10.4.0 on your Leica M10 will add additional functions.

#### Update Contents

Model Number	LEICA M10
Update Version	1.10.4.0
Update Filename	M10-1.10.4.0-CUSTOMER.FW

#### Overview

Version	Description
Version 1.10.4.0	– Support for the new Thambar-M 90 f/2.2 – Support for the new Noctilux-M 75 f/1.25 ASPH.

#### Please follow these steps to install the new firmware for your Leica M camera:

Recharge the battery to 100% and insert the battery into the camera.

1. Download the new firmware file to your computer.
2. Prepare the SD card for installation:
  - a. Please make sure that the card contains at least 200 MB of free disk space.
  - b. It is recommended to format the card inside the camera before continuing
  - c. Download the new firmware file to your computer.
  - d. Copy the firmware file to the root directory of the SD card.
  - e. Eject the SD card properly from your computer.
3. Insert the SD card into the camera and switch the camera on.
4. Go to Main Menu / Camera Information / Camera Firmware
5. Press “Yes” to confirm and start the process;
  - a. Please confirm to save your current profiles to SD card before proceeding with the update.



- b. Wait until the update installation is completed.
  - c. Restart the camera, do not eject the SD card.
  - d. Please load your last profiles from SD card after the first startup.
6. The update process is complete.

**CAUTION:**

Please do **NOT** turn off your camera or remove the Battery or SD Memory Card while the update is running.

**DISREGARDING THIS ADVICE CAN CAUSE SERIOUS DAMAGE TO YOUR CAMERA!**